



SCUTTLE Robot Kinematics Guide

revised 2025.06

Author: David Malawey

Copyright 2025 SCUTTLE Robotics LLC



Contents



This Guide Covers:

- Robot geometry, r, and L
- Key variables: phi, x, y, and theta
- Kinematic equation: convert wheel speeds to chassis speeds
- Inverse Kinematic equation: convert chassis speeds to wheel speeds
- Time-derivatives of the wheel and chassis displacements
- Rotation matrix to convert body-fixed coordinates to global coordinates


SCUTTLE Coordinates

magnetic North



Our Axes & Coordinates:

- The x-global is often decided to be aligned with magnetic North.
- The x-robot is aligned with the chassis, forward
- In this diagram, x-global is the axis and x-scuttle is bot axis
- Theta describes the orientation of the bot, in global coordinates




IMU Sensor



If your bot has an IMU (inertial measurement unit) then:

- The IMU reports values in the orientation of itself.
- You must translate or rotate the IMU reading if the sensor is mounted differently than forward.
- For beaglebone blue, the IMU has a y-axis pointing along the USB port.



The beaglebone blue includes an IMU with the y-axis as shown.

Non-Holonomic System


A holonomic robot has the same number (or more) of controllable degrees of freedom as the number of degrees of freedom.

SCUTTLE DOF: (x, y, theta)

CONTROLLABLE DOF: (left motor, right motor)

Mecanum Robot DOF: (x,y,theta)


In a non-holonomic system, the final position of the robot depends on the path taken to achieve the movement.







Chassis Geometry

- The Chassis Geometry determines the equations for kinematics.
- The radius, r, is the radius of the driven wheel
- The half-wheelbase⁽¹⁾, L, is the space from wheel center to center divided in two






Parameters



```
\dot{\phi}_L = pdl, as in phi_dot_l
\dot{\phi}_R = pdr, as in phi_dot_r
```


```
phiDots = np.array([pdl, pdr]) # python
syntax
```



Rotation Matrix

- Theta describes the difference between the body-fixed frame and the global frame.
- The **rotation matrix** converts body-fixed coordinates to the global coordinates


$$\begin{bmatrix} x' \\ y' \end{bmatrix} = \begin{bmatrix} \cos(\theta) & -\sin(\theta) \\ \sin(\theta) & \cos(\theta) \end{bmatrix} \begin{bmatrix} x_{bf} \\ y_{bf} \end{bmatrix}$$



Kinematic Equation

- Phi is the angle of the wheel.
 - It is used to define incremental changes in wheel position and to calculate wheel speeds
- The x,y coordinate system has x pointing forward on the bot.
 - Positive movement of both phi's result in positive movement of the robot along the x-direction
- The Kinematic Equation generates chassis motion information.
 - input the wheel speeds and output the (translational and rotational) chassis speeds


$$\begin{bmatrix} \dot{x} \\ \dot{\theta} \end{bmatrix} = \begin{bmatrix} R/2 & R/2 \\ -R/2L & R/2L \end{bmatrix} \begin{bmatrix} \dot{\varphi}_L \\ \dot{\varphi}_R \end{bmatrix}$$




Encoder

The encoder measures the motor rotation by magnetic sensing.

- Readings are reported in 14-bit integers
- Values are always positive, from 0 to 360
- Encoder reports fixed positions and we derive speed from the changes over time
- Two motor turns = One wheel turn



contactless encoder, and magnet




Wheel Rotation

- Phi is the angle of the wheel.
 - Use the right-hand-method to identify the forward direction for phi
 - Let 'a' be the encoder reading (from 0 to 360)
 - Let 'N' be the small:large pulley ratio
 - Then,

$$\varphi_R = a_R * N$$

$$\phi_L = (360 - a_L) * N$$



SCUTTLE wheel rotation vectors, phi-left + phi-right


Inverse Kinematics




- Inverse Kinematic equation:
 - Input the desired speed and angular speed, and output the left and right wheel speeds.
 - These equations are written in the robotfixed frame

$$\begin{bmatrix} \dot{\varphi}_L \\ \dot{\varphi}_R \end{bmatrix} = \begin{bmatrix} 1/R & -L/R \\ 1/R & L/R \end{bmatrix} \begin{bmatrix} \dot{x} \\ \dot{\theta} \end{bmatrix}$$

matrix multiplication: [C] = [A][B]





Kinematics Guide

Robot Frame



Forward and inverse kinematics in the robot frame:

"Kinematics"
Use the **wheel** speeds to obtain the **chassis** speeds

"Inverse Kinematics"
Use the chassis speeds to obtain the wheel speeds

$$\begin{bmatrix} \dot{x} \\ \dot{\theta} \end{bmatrix} = \begin{bmatrix} R/2 & R/2 \\ -R/2L & R/2L \end{bmatrix} \begin{bmatrix} \dot{\varphi}_L \\ \dot{\varphi}_R \end{bmatrix}$$








Use Case

How do we use inverse kinematics?






Coordinate Frames

Describing the robot in the inertial (global) frame:

- The global frame is selected by the user and fixed to the earth. It maybe the corner of a room.
- From the global frame we can measure inertia, so it may be called the inertial frame.
- P0 is the robot location, in the global frame.
- P0 is defined by the center of the wheelbase.

$$q^{I} = \begin{bmatrix} x_{a} \\ y_{a} \\ \theta \end{bmatrix}$$




Body-Fixed Frame

Coordinate Frames

The body-fixed-frame is the coordinate system fixed to the robot.

- the body-fixed frame is used to describe obstacles or room locations.
- the robot's own location in this frame is zero for x, y, and theta.
- if the robot gains a module, it is useful to define in the body-fixed-frame.





x-dot may be positive or negative

Kinematics for ROS



ROS (robot operating system) offers documentation with some standard methods for robotic motion and the components thereof. Motion is described using a twist message to command an actuator. Think of twist as a combination of translation and rotation.

Within ROS documentation, this topic falls under robotic navigation or path planning.

https://wiki.ros.org/navigation/Tutorials

What is a twist message?

"[Twist.msg] expresses velocity in free space broken into its linear and angular parts"

-ROS documentation

Motion Variables

ROS	SCUTTLE
speed.linear.x	x_dot or xd
speed.linear.y	always zero
speed.linear.z	always zero
speed.angular.x	always zero
speed.angular.y	always zero
speed.angular.z	theta_dot or td

How to relate ROS twist components with SCUTTLE?

Kinematics for ROS

First diagram shows how the ROS node (blue rectangle) lives in a package, and interacts with other packages.

What is a ROS node? Simple explanation

Motion planning pkg

Motion planning

Path correction


Hardware control

State publisher

Main Control loop


Drivers

Naming conventions for mobile platforms by ROS.org



Speeds

- What values should I target for motion? The chart shows peak speeds for the standard SCUTTLE with 12v battery.
- Rotation can be made at 0.75 radians per second while driving 0.3 meters per second forward
- Rotation can be made above 1.5 radians per second while forward speed is zero (a point turn).



Twist.msg elements above, common (achievable) values to move SCUTTLE





- Use the units below in your commands for motion, inside the twist.msg
- Gather more information in the REP archives of ros.org

Units

ROS	SCUTTLE
speed.linear.x	meters per second
speed.angular.z	radians per second

What units are used for the twist message?

Reference

REP: 103

Title: Standard Units of Measure and Coordinate Conventions

Author: Tully Foote, Mike Purvis

Status: Active

Type: Informational

Content-Type: text/x-rst


Created: 07-Oct-2010 **Post-History:** 31-Dec-2014


https://www.ros.org/reps/rep-o103.html


All recommended units by ROS.org

Wheelbase

- The true wheelbase is determined by the contact patch of the wheels on the ground.
 - wheels have a *draw angle* from the manufacturing mold, resulting in a larger inner diameter.
 - Then, the contact patch may lie closer to the robot center, especially with no payload.
 - The inner wheel edge gives a 355mm wheelbase.
 - The wheelbase may change when a heavy load compresses the urethane.







Wheelbase



Kinematics Sources:





 Dhaouadi, Rached, and A. Abu Hatab. "Dynamic modelling of differential-drive mobile robots using lagrange and newtoneuler methodologies: A unified framework." Advances in Robotics & Automation 2.2 (2013): 1-7.




2. Hur, Byul, et al. "Open-source Embedded Linux Mobile Robot Platform for Mechatronics Engineering and IoT Education." *Journal of Management & Engineering Integration* 13.2 (2020): 34-44.




3. Achmad, MS Hendriyawan, et al. "ROS-based 2-D Mapping Using Non-holonomic Differential Mobile Robot." *JURNAL INFOTEL* 10.2 (2018): 75-82.

Images


Use these images for slides & plans



SCUTTLE version 3.0 with Raspberry Pi



encoder, AS5048B



SCUTTLE version 2.4